












1. Roll out Controlit GS single ply on the surface with 100mm overlap




2. Mechanically fix the waterproofing




3. On vertical surfaces Controlit GS single ply is always 1/3 below waterproofing level




2. Take out the cut detail



3. Cut the two lines in the cross shape in Controlit GS single ply




4. Now you can freely unfold the Controlit GS single ply




5. Install A detail below unfolded Controlit GS single ply







6. Fold back unfolded Controlit GS single ply




7. Install B detail. Controlit GS single ply is not between A and B details




8. Use roofing material to cut out a circular patch. Place it above detail A,B.




9. Install D detail




10. With hot air or flame shrink E detail



11. Apply F detail







12. Ready connection contact




Attention! Installation of Controlit simultaneously with the waterproofing membrane according to the membrane installation instructions issued by the manufacturer.


2





1. Roll out Controlit GS on the first layer of waterproofing with 100mm overlap




2. Melt or mechanically fix the second layer of waterproofing directly on Controlit GS.




3. On vertical surfaces Controlit GS is always 1/3 below waterproofing level




1. Cut the two lines in the cross shape in Controlit GS




2. Install A detail below unfolded Controlit GS



4. Install B detail. Controlit GS is between A and B details



6. Install D detail




7. With hot air or flame shrink E detail

2.1




2.1


www.controlitfactory.eu




8. Fix the second layer of waterproofing directly on Controlit GS




9. Cut line in the second waterproofing layer




10. Fold second waterproofing layer from both sides of the connection contact




11. Connection contact is now hermetically sealed between two overlaps







12. Apply F detail




13. Ready connection contact




Attention! Installation of Controlit simultaneously with the waterproofing membrane according to the membrane installation instructions issued by the manufacturer.




1. Roll out Controlit GS on the surface with 100mm overlap





2. Melt or mechanically fix first layer of waterproofing




3. Melt or mechanically fix the second layer of waterproofing




4. On vertical surfaces Controlit GS is always 1/3 below waterproofing level




1. Cut the two lines in the cross shape in Controlit GS



2. Install A detail below unfolded Controlit GS




4. Install B detail. Controlit GS is between A and B details




6. Install D detail




Attention! Installation of Controlit simultaneously with the waterproofing membrane according to the membrane installation instructions issued by the manufacturer.




7. With hot air or flame shrink E detail




8. Fix the first layer of waterproofing directly on Controlit GS




9. Cut line in the first layer of waterproofing




10. Fold the first layer of waterproofing from both sides of the connection contact




11. Connection contact is now hermetically sealed between two overlaps




12. Fix the second layer of waterproofing




13. Cut line in the second layer of waterproofing



14. Fold the second layer of waterproofing from both sides of the connection contact



15. Connection contact is now hermetically sealed between two overlaps. Apply F detail



16. Ready connection contact



Attention! Installation of Controlit simultaneously with the waterproofing membrane according to the membrane installation instructions issued by the manufacturer.